



# CE 78 RAPIDE

## PLASTERBOARD JOINTING FILLER SETTING TIME 4 HOURS

### TECHNICAL DEFINITION

CE 78 RAPIDE is a powder filler designed specifically for jointing tapered edge plasterboard in combination with a joint tape.

4 hours mix working life.

### COMPOSITION AND APPEARANCE

Powder filler based on plaster, calcium carbonate, resin and various additives.

The paste obtained is white.

### SUITABLE SUBSTRATES

All types of plasterboard with or without insulation (glass wool, rock wool, polystyrene) with tapered edges and paper face.

### COVERING

- Primer undercoat for plasterboard
- Plaster-based smoothing filler

### DOCUMENTS TO BE CONSULTED

- DTU 25.41 and 25.42.
- Certificate QB N° 311-16-732.
- CE marking.

### TECHNICAL CHARACTERISTICS

- Setting time: 4 hours.
- Strip adhesion: > 1,000 g.
- Cracking: no cracking up to 5 mm thickness.
- Density: 0.9
- A1 class reaction to fire.

These characteristics are confirmed by the technical report.

### PACKING

5 and 25 kg bags.

### STORAGE

9 months in original unopened package, protected from damp.

## APPLICATION

### PRECAUTIONS FOR USE

The temperature during application and drying must be between 5 and 30° C.

Do not apply to damp substrate.

Do not use mix that has begun to set.

The association of this compound with self-adhesive reinforced tape is not recommended and is not included in the Technical Approval: a paper tape drowned in the compound is much stronger mechanically than a self-adhesive tape stuck directly on the board to which the compound is applied to its exterior face only.

### PREPARATION OF SURFACE

Plasterboard must be attached in conformity with DTU 25.41.

Cuts made into plasterboard must be on the bevel and dusted.

### MIXING FACTOR

From 10 to 11 l of water per 25 kg sack.

1 volume of water + 2,5 volumes of powder.

### APPLICATION

Before jointing fill gaps between boards and any irregular joints and repair any damaged board.

Apply manually by using a 10 or 15 cm filling knife and apply the tape – milled face against the board. Then apply a finish coat, allow to dry and finish to cover the tape.

Also cover screw heads.

Apply a tape into the ceiling joins and ensure that the concrete is free of any signs of mould-release oil.

For vertical protruding angles use a reinforced tape (metal side against the board) or a metal angle bead.

### ASSOCIATED TAPES

SEMIN tape.

### CONSUMPTION

Approximately 350 g/m<sup>2</sup> of plasterboard.

### DRYING TIME

Second coat may be applied 4 hours after application of the first coat.

## FAST SETTING JOINT FILLER

**JOINT FILLER** Formulated specially for short setting times, **CE 78 RAPIDE** makes for faster work on site.

### ADVANTAGES

- Ideal for cold and wet weather.
- High quality finish.

### APPLICATION TIP

**To prevent furring do not sand the paper face of the board before applying the primer.**

CERTIFICATE QB N° 311-16-732



COLD AND WET  
WEATHER

